## Connection & Installation

Please install the Zener barrier and power supply in a non-hazardous area.

Use a CVVS-2 core shielded cable (0.75sq or more) for connection.

And keep the length of the cable between the detector and Zener barrier within 400m.

\*When connecting devices, make sure that each serial number matches. When you connecting devices, make sure that each serial number matches.

